

Features available without a license




To get the most out of the software you will need a license. Without a license you can only re-generate an existing report. This will guide you through this process.



Please note, any data shown within the guides is used for visual purposes only, and does not represent actual data.


1

Without a license, you will see the following notice when trying to do most things in Inclopro Insight.




2

You will be able to load an existing site file by clicking 'Open Site' and selecting a site file to load.




3

Going into Manage Reports, you can select the report to re-run.




4

You will be prompted that all controls are disabled and that you can only re-generate an existing report template.



5

Click 'Generate Report (Export)' to generate the existing template.



Managing Your License - How does it work?



This guides talks you through how licensing works and how to activate yours within the software.


1

Licensing is based on a primary license key that can contain multiple sub licenses, allowing organisations to manage several users under a single key. Sub licenses typically last for one year and activate when the software is first setup by Geosense. Once active, the software periodically checks in with Geosense GeoConnect to verify status.

The built in smart allocation system ensures fair and efficient use: if a user remains inactive for more than two days, the sub license may automatically de allocate so another user can claim it. Licenses can also be manually released at any time to return them to the available pool. When working offline, the software will retain an activation for up to 30 days before requiring an internet connection to re validate. This flexible licensing structure makes it easy to manage usage across teams while preventing unnecessary lockouts.

2

When you open the software for the first time, or open a site without a license you will be prompted to enter your license information on the screen below. You can copy and paste the license from the email you will have received from Geosense. A valid email address will also need to be added to activate.



3

After activation you can De-Allocate your license on the same screen by pressing De-Allocate. This puts it back in the available pool for re-allocation.